

# **RESIBLOCK O.R.**

- 1 Stir well before use.
- 2 Liberally apply **RESIBLOCK O.R.** to stain and agitate with a bristle brush.
- 3 Allow to soak for 15 minutes (do not allow to dry out) and repeat as necessary.
- 4 Thoroughly rinse with detergent and pressure washer.
- 5 Seal concrete block pavers with **RESIBLOCK SUPERIOR** or **RESIBLOCK SUPERIOR NATURAL MATT** to prevent re-staining.

**STORAGE & HANDLING** Do not store near foodstuffs. Replace lid after use. Wash hands and exposed skin after use.

**HEALTH & SAFETY** It is not essential to wear full protective clothing, but eye protection should be worn by the operator to prevent spray entering and inflaming the eyes. PVC or rubber gloves should be worn as prolonged skin contact could cause irritation.

Keep away from children. Read safety panel on container.

**FIRST AID** Eyes: If accidentally splashed into eyes irrigate thoroughly with clean water for 15 minutes. Seek medical attention if irritation persists.

Skin: Prolonged contact is not advisable. Wash off thoroughly with soap and water.

Ingested: Do not induce vomiting. Drink plenty of water followed by milk. Seek medical advice immediately.